

Technical Details:

- Supports Sockets AM2, AM2+, AM3, AM3+, AM4, FM1, FM2, FM2+
- Ports: G1/4"
- LED Holes: 3mm


Box Contents:

- 1x RayStorm Waterblock
- 1x 3mm Twin LED
- 1x AMD Screw Set
- 1x K3 Thermal Paste




The installation process below is shown without the tubing connected. This has been done so the installation process can be seen clearly. All watercooling components should be connected and leak tested prior to installation into a PC.


Preparing AM#,FM# Sockets




1. Remove the plastic clips on either side of the CPU socket by undoing the 4 screws.



2. If the backplate is loose, place it back in its correct position. Make sure the 4 screw threads on the backplate line up with the holes on the motherboard.




3. Place a nylon washer over the short end of each post and screw it into each of the four holes around the socket.



Continue over page >

Fitting the Waterblock (AMD)


The installation process below is shown without the tubing connected. This has been done so the installation process can be seen clearly, without any obstructions.




1. Remove the plastic film from the base of the waterblock.



2. Apply a thin layer of thermal paste to the CPU's heat spreader.




3. Place the waterblock over the posts and onto the CPU.




4. Place a plastic washer and metal washer over each of the four posts. *If using socket AM4 use two plastic washers and one metal washer.*



5. Place a spring over each of the four posts.



6. Place a nut onto each post and gradually tighten them. You should tighten each nut in stages. e.g. 1,2,3,4,1,2,3,4,1,2,3,4, until each nut is fully tightened.



7. Push the LEDs into either side of the waterblock.



8. The block is now ready to use. When you first boot it is advisable to use software to check the core temperature. If the temperature is high you will need to remount the block.